



NOTE: INSTALL 14 GAUGE INSULATED COPPER TRACER WIRE FULL LENGTH OF PIPE. LEAVE PUMP END CLEARLY SHOWN AND MARKED INSIDE TANK. WHEN CONNECTING TO EXISTING TRACER WIRE, USE A WATER TIGHT WIRE CONNECTOR OR INSTALL C.O WITH BOTH ENDS OF TRACER WIRE CLEARLY EXPOSED ABOVE FINISHED GRADE.

TO ORDER PUMPS, TANKS, AND LATERAL ASSEMBLY, CONTACT:

CORRECT EQUIPMENT, INC.  
 300 S REDWOOD ST  
 CANBY, OR 97013